

MIDGET MUSTANG TIE DOWN OPTION

This addendum shows one method of adding tie-down hard points to the Midget Mustang. The tie-down brackets can be easily added to a completed airplane as they are simply added to the bolted gear leg assembly.

The main gear leg will need to be removed. After fabricating and forming the bracket it is clamped in position on the main gear leg. Match drill through the forward two gear attach holes. Replace these two AN6 bolts with longer ones sufficient to at least protrude slightly through the nut after installation. The original bolts pictured below need to be replaced with the next size longer bolt.

